

MONACO LUXURY POLISHED GOLD SOLID BRASS BATHTUB FAUCET SET W/ CERAMICS HAND SHOWER SPRAYER INSTALLTION INSTRUCTIONS



BEFORE YOU BEGIN

Before installing, read entire Installation Instructions. Observe all local building and safety codes.

For the following installation instructions for your new product it is assumed that any old fixtures have been removed and any repairs or modifications to the water supply have been completed. Unpack and inspect the product for any shipping damages. If you find damages, do not install.

Contact Customer Service at 703-378-1915. If you need assistance or have questions while installing your product, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures.

TOOLS REQUIRED*



Plumber's Tape



Basin Wrench



Thread Sealant



Screwdriver



Adjustable Wrench



Hex Wrench

*not included

INSTALLATION

1. If your faucet comes with the brass T attached to the faucet body, unthread and remove the T and associated hardware.
2. Thread the mounting washer and rubber sealing gasket on the faucet body and thread the faucet body through the center mounting hole.
3. Thread the mounting hardware and brass T onto the body and hand-tighten to secure.
4. Check to make sure the faucet is properly aligned and adjust as needed. When the faucet is in the proper position, finish tightening mounting hardware with your adjustable wrench.
5. Disassemble the handle bodies. You may need to remove set screws located on the side of the handles with the provided Allen wrench.
6. Insert the handle bodies up through the mounting holes. Secure the handle assemblies to the handle bodies. Make sure that the rubber sealing gasket is between the handle and the mounting surface to ensure a watertight seal.
7. With both handles in the OFF position, tighten the set screw on the top or side of the handle with the Allen wrench
8. Attach the hot and cold flexible water feed tubes to the handle bodies and brass T. (Hot water is always on the left and cold water is always on the right). Curve tubes as necessary to ensure there are no kinks or knots.
9. Connect the main water supply to the faucet body.
10. If your faucet features a hand shower and diverter, follow steps 6-8 listed above and attach the water feed tubes accordingly.
11. After all, connections have been made, turn on the water supply, check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the faucet on and allow the water to flow through the spout for approximately 60 seconds. If you have a hand shower, divert the water to the hose and allow the water to flow through the hose for an additional 60 seconds.



